


About the menu bar

The image shows a dark grey menu bar with three items: 'TRACKER' with a keyboard shortcut 'T', 'WINDOW' with a keyboard shortcut 'W', and 'HELP' with a keyboard shortcut 'H'. The text is white and the bar has a slightly distressed, torn-edge appearance on the right side.

The Vicon Tracker menu bar contains the following menus.

Menu	Options	Description
Tracker	Undo	Undoes the last action. This command is available only after a relevant action has been performed.
	Redo	Reinstates the previously undone action. This command is available only after an Undo command has been performed.
	Exit	Closes the Tracker application window. If you have not saved any changes, Tracker displays a prompt to enable you to save changes before it closes.
Window	New Floating Workspace	Opens a separate floating view pane.
	Resources	Displays or hides the Resources pane in which you manage the components of your Vicon Tracker system and the objects whose motion is to be captured. To display the pane, select the check box next to the option.
	Communications	Displays or hides the Communications pane in which you view the state of your Vicon Tracker system. To display the pane, select the check box next to the option.
	Sounds	Displays or hides the Sounds dialog box. For more information, see Instant auditory feedback in What's New in Vicon Tracker .
	Options	Displays the Options dialog box in which you control the way data is displayed in view panes. The Options dialog box can also be displayed by pressing F7.
Help	View Online Help	Opens the online Vicon Tracker Help system.
	View User Guide	Opens a PDF of the Vicon Tracker User Guide that was installed with Tracker.
	Check for Updates	Checks the currently installed version of Tracker and enables you to update it if necessary.
	About Vicon Tracker	Displays the Vicon Tracker startup screen, in which you can view version information about the installed release of Tracker.
	Vicon Product Licensing	Opens the Vicon Automated Unified Licensing Tool (VAULT), which enables you to manage licenses. For more information, see License Vicon Tracker .